Click on Display Orientation.

Click on Auto to select it. Note: this is the default setting.Once activated the circle next to the selection turns blue.

Click on Portrait to select it. Note: Once activated the circle next to the selection turns blue.

Click on Landscape to select it.   Note: Once activated the circle next to the selection turns blue.

Click on OK.

That's it. You're done.

Scan to go to the interactive player